



Infection Control Aspect on Environmental Standard on Commissioning

Dr. Raymond Lai
28 Feb 2012






Timeline of Preparation with Infection Control Team




- Steering Committee on Commissioning
- Meetings started from 2008
- Standardization Committee
- Ventilation
- General ward settings related to infection control
- Patient flow
- Work flow


Ground Floor 地下




威爾斯親王醫院新住院主樓暨創傷中心




3rd Floor 三樓




5th Floor 五樓







Isolation OT



CSSD & TSSU Sterile store






CSSD / TSSU - Consideration


- Well segregated clean and dirty zone
- Double doors sterilizers and washer disinfectors – one way in and the other way out
- Installation of R/O machine to generate purified water and steam
- Replace linen with disposable wrapper and drapes – pass the particle count required in the ISO 14644 class 8 standard
- Consider the space for central disinfection / sterilization
- Avoid to have water pipes and sewage pipes above the ceilings of CSSD / TSSU






4/F ICU


**(Prepared for Infectious
Disease Epidemics)**









12th Floor 十二樓







Isolation ward – patient cubicle




8th Floor 八樓









General ward – Gown Up and Gown down




General ward – Isolation room






Old waste chute in Old Block






New waste storage area





Clinical waste room





Checking on Completion




Isolation room monitoring panel



Standardization



Site discussion



Cubicle items



Gown up PPE



Poster



AHR set up



除防護裝備 請跟次序

Removing PPE
Step by Step

- 1 除手套**
Remove Gloves
- 2 潔手**
Perform Hand Hygiene
- 3 除隔離衣**
Remove Gown
由內向外折返
Folding Inside Out
- 4 潔手**
Perform Hand Hygiene
- 5 除帽及護眼罩/
全面罩**
Remove Disposable Cap
and Eye Protection
- 6 潔手**
(或消毒)
Perform Hand Hygiene
(Optional)
- 7 除口罩/
N95口罩**
Remove Mask /
N95 Respirator
- 8 再潔手**
Perform Hand Hygiene
AGAIN

注意：摘除的防護裝置應置於專置物架
H.S.: Disposable PPE should be properly disposed in designated areas.



N95呼吸器配戴方法 Use of N95 respirator



Positive Pressure Test

- * Place both hands completely over the respirator and exhale.
- * If air leaks around respirator edges, readjust the nosepiece and straps accordingly

Remember Fit Check 請緊記密合性檢查


正壓測試：

- * 以雙手遮著口罩，然後大力呼氣。
- * 如空氣從口罩邊緣溢出，表示佩戴不當，必須再次調校頭帶及鼻樑金屬條。



新界東醫院聯網 感染控制組 2006
NTEC Infection Control Unit 2006

N95呼吸器卸下方法 Removal of N95 respirator



新界東醫院聯網 感染控制組 2006
NTEC Infection Control Unit 2006

穿防護裝備 請跟次序

Donning PPE
Step by Step

- 1 潔手**
Perform Hand Hygiene



戴口罩/ N95口罩

Put on Mask /
N95 Respirator

* 請緊記密合性檢查
Remember Fit
Perform Seal Check

- 2 戴護眼罩/
全面罩及帽**
Put on Eye Protection
and Disposable Cap



戴護眼罩/ 全面罩及帽

Put on Eye Protection
and Disposable Cap



戴隔離衣

Put on Gown



戴手套

Put on Gloves


注意：選用中國製造的中國標識的防護裝備
N.B.: Selection of PPE should
be based on risk assessment





rubbish bin with lid

Large	Medium		
Gown down area	1	Cubicle	6
Dirty utility	1	Gown up area	1
Treatment room	1	Isolation rooms	2
Toilet	2	Corridor	2
Assisted bath	2	Nurses station	3
660L refuse bin for domestic waste	1	Equipment store	?
		General store	?
		Interview room	1
		Day room	1
		Staff toilet	1






新大樓 ■ 新面貌



Patient areas




Patient Toilets




新大樓 ■ 新面貌



護士站



升降機



Thank You!

